



SANKO Coating Thickness Meter SWT-7200IV Instruction Manual



Caution

- Read the manual thoroughly and use the meter correctly.
- Keep the manual with care and refer to it when necessary.

SANKO ELECTRONIC LABORATORY CO., LTD.

Tokyo · Osaka · Sendai · Nagoya · Fukuoka · Kawasaki

August 2023

Contents	Pages
Attention for safety	1
Notes	3
Get started	4
• Contents in a package	4
• Names of part	5
• Items displayed on LCD	7
• How to fit batteries	9
• How to connect, disconnect probes	10
• How to hold probes	11
• How to press a probe to an object	11
How to operate	12
(1) How to switch power source	12
(2) How to switch off	12
(3) How to select 「Cal. No. 」 (Calibration curve)	13
(4) Zeroing	14
(5) Calibration standard (CAL)	16
(6) Zeroing — in special cases —	18
(7) 2-point calibration in case it is difficult to perform 「Zeroing」	21
(8) How to delete calibration	25
《Collective deletion》	25
《Selective deletion》	26
Measuring	27
Function setting	28
(1) Setting of Non-Interrupt Measurement Mode	28
(2) Setting of resolutions	30
(3) Setting of units	31
(4) Setting of Auto-Power-OFF function	32
(5) Setting of corresponding mode to substrate with SFN-325 probe	34
(6) Setting of Backlight	35
Setting of High/Low limit values	36
(1) Setting of High limit value	36

(2) Setting of Low limit value	37
(3) Deletion of set High/Low limit values	38
Measurements with High/Low limit values	39
(1) When measured value within a range of limit value	39
(2) When measured value over a High limit value	39
(3) When measured value below a Low limit value	39
Storing of measured data	40
(1) Select a Data storing place	42
(2) Keep data from being stored	46
Measurements in storing data	47
Storing of measured data at Non-Interrupt Measurement Mode	51
Three kinds of measuring methods in case of 「No memory space」	52
(1) Keep on measuring	52
(2) Look for an empty storing space	52
(3) Deletion of unnecessary data	53
Deletion of data	53
(1) Deletion of one data	53
(2) Deletion of all data	54
(3) Deletion of group data	55
(4) Deletion of block data	57
(5) Deletion of section data	60
Statistics	63
(1) Statistics of all data	63
(2) Statistics of group data	64
(3) Statistics of block data	66
(4) Statistics of section data	69
Transferring data — USB —	72
(1) Outright transferring measured data (Real time transfer)	72
(2) Interrupt transferring data	73
Transferring stored data — USB —	74
(1) Transfer of all data	74
(2) Transfer of group data	75










(3) Transfer of block data	78
(4) Transfer of section data	81
Note to improve measuring accuracy	84
Trouble shooting	85
Disclaimer	86
Specifications ◆ main unit	87
◆ probe (option)	88
References (measurement principles)	91

Attention for safety (to use safely and correctly)

To prevent you and your properties from damaging please take some time to read thoroughly this “Attention for Safety” and use this main unit correctly.

And keep these instructions attentive to read when necessary.















-  ● Do not dump nor wet the main unit in water, otherwise it may cause malfunctions.
Prohibition Please contact our distributor or sales office should submerged water into the main unit.
-  ● Do not insert metals or foreign substances into the main unit, otherwise it may cause malfunctions.
Prohibition Please contact our distributor or sales office should put any metals or foreign substances in the main unit.
-  ● Do not insert a screwdriver into the connector, otherwise that it may cause malfunctions.
Prohibition
-  ● Do not throw, smash, drop the main unit, otherwise it may cause injuries, damages, malfunctions.
Prohibition
-  ● Never dismantle or modify the main unit by yourself, otherwise it may cause errors reactions or damages.
Prohibition
-  ● Do not use AC adaptors other than an exclusive adaptor for this main unit.
Prohibition ✘ And do not use volatage other than the specified voltage, otherwise it may cause damages, electric shocks, fires.
-  ● Keep the terminal of AC adaptor from conductive substances or dirt, otherwise it may cause short circuits, electric shocks, ignitions and fires.
Prohibition
-  ● Do not handle the AC adaptor with wet hands, otherwise it may cause electric shocks.
Prohibition
-  ● Do not damage, brake, modify, forcefully bend or twist the cord of the AC adaptor. Or, do not load it with heavy staff or pinch it forcefully, otherwise it may cause damages, breaking wires, short circuits, electric shocks, fires.
Prohibition

Attention for safety (to use safely and correctly)







Warning

-  ● Never fail to remove batteries from the main unit when not in use for a long time.
Must Leakages occurred from deterioration of batteries may cause erroneous reactions or damages.
-  ● Be sure to read this book on the item of 「How to fit batteries」 to replace batteries.
Must
-  ● Store batteries in a place where pets and children are incapable of handling them.
Must Please call a doctor like in a case that a battery is swallowed.
-  ● Do not put batteries into fire or water. Store them in a cool, dry and dark place avoiding flames, high temperature and moisture.
Must
-  ● Do not get batteries shocked and dismantled, and soldered for processing
Must
-  ● Do not short or recharge batteries and handle with metallic tools like pliers.
Must
-  ● Replace with specified, new batterie (watch: battery life).
Must Some special dry batteries (nickel batteries) may not work properly.
-  ● Be sure of paying attention on battery polarity marks, (+、-) to place the batteries.
Must
-  ● In case a battery has leakage please clean up the place with cloths to replace batteries.
Must And do not touch the leaked liquid and wash skins or clothes in case they are contaminated.
-  ● Comply to regulations and laws in your neighbors when disposing of them.
Must
-  ● Insert a plug of the AC adaptor to the full end.
Must And do not use faulty or loose receptacles, otherwise it may cause electric shocks and fires.
-  ● Switch to OFF and unplug the AC adaptor from the receptacle to avoid electric shocks and injuries when inspecting or cleaning the main unit.
Must

Attention for safety (to use safely and correctly)



Attention

-  ● Do not use Benzene or Thinner for cleaning and spray pesticides on the meter, otherwise it may cause cracks or malfunctions.
Prohibition
-  ● Do not store the meter in places getting high in temperatures such as in a car in strong sunlight or near heaters, otherwise it will be hazardous to the meter and may cause malfunctions.
Prohibition
-  ● Do not step, trample down nor put anything on the meter, otherwise it may cause malfunctions or injuries.
Prohibition
-  ● Keep the meter away off rubber-made articles or vinyl articles. A lengthy contact between the meter and them may cause stickiness and it may be difficult to get rid of them.
Prohibition

Notes

- Please read this manual thoroughly for correct operations before getting started.
- This meter is a precision gauge. Please handle with care.
- Do not tug, bend, fold or curl up forcefully the cables of probes.
- Do not knock or scratch objects with the tip of a probe.
- Keep the tip of a probe clean. A slight amount of dust may cause errors in measurements.
- Clean the meter and store it in free from dust and moisture after operation.
- To keep precision with a gauge please contact us for a periodical inspection.
- Keep the meter away off electric noises, shocks or magnetic fields when in a use, otherwise it may cause malfunctions.

Get started

◆ Contents in a package Please make sure if the following items are included.

- Main unit
SWT-7200IV

- Dry batteries LR6 (2 pieces)

- SWT/SAMAC series CD
 - ◆ SWT-7200IV Instruction Manual (this manual)
 - ◆ USB driver
 - ◆ Installation of USB transfer driver

- Inspection certificate (warranty)-cum-user registration sheet
(This warranty is valid only in Japan)


- Hand strap cord (attach directly to main unit)

- Carrying case for main unit

- AC adaptor

- USB cable

◆ Names of part



● Probe connector





Connect an optional-exclusive SWT probe to the probe connector.

- (1) To measure a film thickness of coated, plated, lining layer on substrates made of ferrous material please use a probe of 「SFe」 series for the connection.
- (2) To measure a film thickness of coated, lining layer on substrates made of non-ferrous materials such as Aluminum, etc. please use a probe of 「SNFe」 series for the connection.
- (3) To measure a film thickness on a coated metal substrate made of either ferrous or non-ferrous please use a Dual type probe 「SFN-325」.

● Display


It indicates measurement results, operation guides, or malfunction status. With a backlight.

● Keys

- (1) 「」 (Power source) key
It switches ON or OFF.
- (2) 「ZERO」key
To set a ZERO point of substrate before measuring.
- (3) 「」key、 「」key
They are Backlight key / an adjusting key to set a numerical value for standard adjustments.
- (4) 「CAL」 key
This is to start up and finish the Calibration standard, and delete an abnormal value taken during adjustment process.
(activates only when 「Zeroing」, 「Calibration standard」 is processed with combination with 「」 key)

※ Power source key / operation keys activate setting of various kinds of functions in combination with other keys.


- (5) 「CAL No.」 key
It is a key to select a Calibration curves.
 - (6) 「H/L」 key
It is a key to set High/Low limit values.
 - (7) 「STATISTICS」 key
It is a key to process statistics of data stored in memory.
 - (8) 「MEM. SEL.」 key
It is a key to select memory area to store memory.
 - (9) 「COM. ENABLE」 key
It is a key to select a method for data transfer.
 - (10) 「TRANSMIT」 key
It is a key to activate transferring process of data process.
 - (11) 「MEM. CLEAR」 key
It is a key to delete data stored in memory.
 - (12) 「DATA ERASE」 key
It is a key to erase one of data displayed on the screen.
 - (13) 「CANCEL」 key
It is a key to interrupt the operation in progress and take an immediate step back to measuring process.
- Hand strap
Hang the meter through a strap over your wrist never to drop it.
 - AC adaptor connector
A connector to connect the exclusive AC adaptor (accessory).
 - USB cable connector
A connector to connect the USB cable for data transfer.
 - Battery compartment
It contains 2 pieces of dry battery (LR6).
 - Tilt stand
Set up the tilt stand to use this meter in a raised position.



Caution

- The tilt stand does not come off. Do not remove it forcibly.
- The tilt stand cannot be used when AC adaptor or USB cable are connected.


◆ Items displayed on LCD



- ① Indicates 「ZERO cal.」 (Zeroing) or 「Cal. w. foil.」 (Calibration Standard), 「2-foil's cal.」 when in process.
It never appears on the reading except when in process of these adjustments.
- ② At Auto Selection mode, one of the three (AUTO), (Fe), and (NFe) is displayed.
At Corresponding mode to substrate, **Fe** is displayed when being setting for exclusively Ferrous substrate, **NFe** for exclusively Non-ferrous substrate.
- ③ Measured data is displayed.
- ④ **BAT** mark is displayed with 2 steps when battery has run out for replacement.
- ⑤ Setted unit is displayed.
“μ m” display automatically switches to “mm” display when it exceeds 999 μ m.
- ⑥ **USB** mark is displayed when data is transferred by USB to PC.
- ⑦ Adjusted values stored in the calibration number and calibration are displayed.
「Cal. No. X *」 *When mark is **[Blank]**,
 Calibration data is not entered (as calibrated at Ex-factory).
 * When mark is **[F_]**
 Zero adjustment value, Calibration standard value of Ferrous are stored.
 * When mark is **[_N]**
 Zero adjustment value, Calibration standard value of Non-ferrous are stored.
 * when mark is **[F N]**
 Zero adjustment value, Calibration standard value of both Ferrous and Non-ferrous are stored.
- ※ Either case indicates Zero adjustment value or Calibration standard only as well.
- ⑧ 「High limit film thickness value」, 「Low limit film thickness value」 is displayed when the High/Low limit values is set. It flashes when a reading value goes beyond a setting limited value.
- ⑨ It displays various items of information in memory storing measuring data.
When measuring while storing data into memory, the number of a storing place is displayed.
- ⑩ Backlight: The light goes on when Backlight is set to ON.

(Sub)

When measuring and watching 「Calibration」, 「High/Low limit values」, 「Memory information of measuring data」, it is possible to enlarge these items on display.



Note: 1. Each number is the same as the forementioned ones of (Main) in its explanation.

2. Items in the ② indicates AUTO, Fe, NFe, **Fe**, **NFe** in English letters.

(Switching of Display Type)

- When outgoing from the factory, the (Main screen) is set in the unit.
- Switching from (Main) to (Sub) screen.
Press **CAL No.** key and **H/L** key together and hold them for 3 seconds or over.
The buzzer beeps 「Beep」, 「Beep」 two times and the (Main) changes to (Sub) screen.
- Switching from (Sub) to (Main) screen.
Press **CAL No.** key and **H/L** key together and hold them for 3 seconds or over.
The buzzer beeps 「Beep」, 「Beep」 two times and the (Sub) changes to (Main).

◆ How to fit batteries

- ① Raise the tilt stand.
 - ② Open the battery lid on the rear of the main unit.
Press 「▽」 mark on the top of the lid and slide it down.
 - ③ Insert batteries.
Ensure correct battery polarity ⊕, ⊖ for placement.
 - ④ Close the battery lid and put the tilt stand back.
- ※ When changing batteries and inadvertently switching ON, but that is not defective at all.




Caution

- Use specified and new (check battery-life) batteries or ones supplied in this package.
- An incorrect use of batteries may cause leakages, bursts. Do not intermingle new ones with different types of batteries.
- Take out batteries to store when not in use for a long absence, or that may cause leakages to breakdown.
- Keep batteries away from pets and children.
- Comply to the regulations and laws in your Local Authorities when disposing of batteries.


◎ About reading display



- When placing batteries in the main unit, the messages and warning below on the screen may be displayed. And these are not breakdowns, wait until the reading disappears with a beeping sound.
- ※ When connecting or disconnecting probe please switch Power source to OFF.



- Batteries have run out when the display on the main unit indicates the mark BAT listed below. Replace with new batteries.



【In case of SFN-325 probe connected】

After Power source switched to ON at Auto mode, (AUTO) is displayed on the screen and when setting exclusively for Fe substrate, or NFe substrate, Fe for a ferrous substrate, NFe for a non-ferrous substrate is displayed.

Also, displayed (Fe) when SFe-probe is connected, and (NFe) when SNFe-probe is connected.


◆ How to connect, disconnect probes

- ◆ Connect an optional, exclusive SWT probe to the main unit
Select one of the probes suited for your application.
 - ◇ If the substrates made of ferrous material, please use a probe of 「SFe」 series or a Dual type probe 「SFN-325」.
 - ◇ If the substrates made of non-ferrous materials such as Aluminum, please use a probe of 「SNFe」 series or a Dual type probe 「SFN-325」.

Insert a probe plug into the probe connector of the main unit.

Make sure of aligning the keyway, push the connector into place until the clasps are locked.

※ If the direction is reversed, it will not enter.




- ◆ Remove the exclusive probe from the main unit.
Pull off the probe carefully by bending inward clasps at the both ends of the probe body to release the clasps.
 - ※ Do not pull off by force or it may cause damages.

Caution

Make sure that Power switches to off when connecting or disconnecting the exclusive SWT probes.

Or else, it may cause damages to connect or disconnect while Power is on.

◆ How to hold probes




Quickly and calmly press perpendicular against the object by grabbing the probe as illustrated. It beeps and the reading screen shows the measuring result.

When it does not beep, lift it 5~7 cm above the object and try again to take measurements.

◆ How to press a probe to an object

- Keep the probe 5 cm or over away off metallic objects when not in use of measuring.
- Press the tip of the probe perpendicular against a measurement object.
 - ※ Tilting may cause large errors.
- Press the probe quickly and smoothly to objects.
 - ※ A slow-acting press may cause large errors.



Caution

- Do not smash or hit the probe against objects, or it may cause damages to probes and to objects.
- Do not scrape, scrub objects with the probe except in a special measurement.
Or it may break the tip of the probe and cause damages to the tip and surface of objects.

How to operate

(1) How to switch power source

Press  key.




The buzzer beeps.

This message lasts for about 3 seconds.



Caution

Hold the probe in air without operation when the reading is on display. Or it may indicate 「ERROR」 and automatically switch off Power.



The Backlight mark is displayed when ON.

【In case of SFN-325 probe connected】

After Power source switched to ON at Auto mode, (AUTO) is displayed on the screen and when setting exclusively for Fe substrate, or NFe substrate, **Fe** for a ferrous substrate, **NFe** for a non-ferrous substrate is displayed.

Also, displayed (Fe) when SFe-probe is connected, and (NFe) when SNFe-probe is connected.

Note: 「Cal. No. 」 ← A number 「1」 is displayed at the firstly switched ON.


From the 2nd on, the last set entry is displayed.

And when 「High limit value」, 「Low limit value」 is set, or when memory is used, the setting values and Nos. are displayed on each column (chained line section).

(2) How to switch off

Press  key.

The buzzer beeps.



The message lasts for about 2 seconds.



Caution

Never remove a probe from a main unit when Power is ON. Or the electric shocks may damage the probe and the main unit


The buzzer beeps and this main unit is switched to OFF.

(3) How to select 「Cal. No. 」 (Calibration curve)

After switching ON, it is capable of getting started on measurements and adjustments when the reading 「START UP PHASE ...」 disappeared.


- ※ Generally, thickness meters make errors depending on material formation and shapes to be measured. To minimize measurement errors and obtain as accurate results, 【Zeroing】 and 【Calibration standard】 are iteratively adjusted before measuring operation. Those adjustment is called 「Calibration curve」.

SWT-7200IV is capable of storing up to 10 sets of calibration data and these data can be called and used when necessary. (the storing place is displayed by a calibration No.)



Indicating positions of (Sub)

Press **CAL No.** Key.
The buzzer beeps.



A number on the display flashes.




Caution

F, N, FN displayed on the 「*」 marked place indicates state of adjusted value stored in the Calibration curve (refer to page 7).

When that value is no more necessary, take「Zeroing」, 「Calibration Standard」.


Stored data can be erased and new data is stored.

Press **▲** key or **▼** key to select your calibration number to use.



A selected number flashes.

Press **CAL No.** key.
The buzzer beeps.



The flashing of the selected number stops
「Cal. No. 8」 is settled.

After settling 「Cal. No. X」, it becomes possible to take measurements and adjustments.


(4) Zeroing

After switching ON, it is capable of getting started on measurements and adjustments when the reading 「START UP PHASE...」 disappeared.

- ※ Generally, the meter makes errors depending on material formation and shapes to be measured.
To minimize measurement errors and obtain as accurate results as possible please be sure of carrying out 2 kinds of adjustments of **【Zeroing】** and **【Calibration standard】** before measuring process.
- ※ Prepare the identical material and shape to a measuring object.
(This is designated as a 「Zero plate」.)


Press **ZERO** key.
The buzzer beeps.

CAL key changes to one data “deletion” function.



Press the probe to the Zero plate.
The buzzer beeps.






Remove the probe from 「Zero plate」.



After pressing certain times or 20 times, press **ZERO** key.



The buzzer beeps.



Calibration No. storing 「Zeroing」 and 「Calibration standard」.

- Repeat a measuring processes, 1~20 times by pressing the probe to the 「Zero plate」.
(A mean value is displayed whenever a probe is pressed)
- ◆ When a measuring process reaches the 20th time, the buzzer beeps, beeps 2 times and afterward new entry is no more accepted.

It stops the "deletion" function of **CAL** key.

The reading **[ZERO cal.]** in the upper left disappears. Zeroing completed and the main unit becomes possible to take measuring and adjusting operations.

Data is stored in 「Cal. No. 8」 and 「F」 is displayed. (refer to page 7)

- Press the probe to the 「Zero plate」 several times and make sure the measuring result indicates in the neighborhood of "0".
When the measured value results in largely off "0", please try again zeroing from the beginning.
There is a case when calibration is not correctly made.
 - "LLLL" displayed on the screen during a time of zeroing means that the calibration point heavily deviates from the standard.
Please make sure that the metal substrate is not processed with other materials such as plating and repeat the zeroing until a stable in the neighborhood of "0" is obtained.
- ※ After performing Zeroing, the previous 「Zeroing value」 is deleted, and the last entry of 「Zeroing value」 is stored.

(5) Calibration standard (CAL)

- Prepare the 「Zero Plate」 used for 「Zeroing」.
- Prepare the 「Thickness standard」 that are the same thick as the measuring film or thicker than that.
- Place the 「Thickness standard」 on the 「Zero Plate」.
- Press key.

The buzzer beeps.

key changes to one data “deletion” function.



【Cal. w. foil】

1. Measure thickness of foil several times.

2. With or . Adjust just to thickness of foil

3. press key.

Press again key to interrupt Calibration standard (CAL).

Press the probe to the Thickness standard on the Zero plate.
It beeps whenever pressing.



cal. w. foil (Fe)

102

μ m

Cal. No. 8 F

Calibration standard is in process.

The measuring object is set for ferrous metal substrate.

Measured a mean value
When the measured value results in largely off the “Thickness standard”, press + key to delete the latest data out of measured values.
It indicates “—” to delete all data.

- Repeat a measuring processes, 1~20 times by pressing the probe to the 「Thickness standard」 on the 「Zero plate」. (A mean value is displayed whenever a probe is pressed)

- ◆ When a measuring process reaches the 20th time, the buzzer beeps, beeps 2 times and afterward new entry is no more accepted.

Adjust the reading value to the Thickness standard (in this case, 100 μ m) by pressing or key.

Pressing or key interrupt the “deletion” function of key.



cal. w. foil (Fe)

100

μ m

Cal. No. 8 F


Pressing key increases the reading value.

Pressing key decreases the reading value.
(Press and holding key turns to fast forwarding.)

Adjust the reading value to the Thickness standard.

After adjusting the reading value to the Thickness standard,
press **CAL** key.

The buzzer beeps, **【cal. w. foil】** on the upper left disappears
and it returns to a measuring mode.




This is a measuring mode.

- It is correct that numerical values measured by pressing the probe a few times to the 「Thickness standard」 on the 「Zero plate」 indicates the thickness in the neighborhood of the 「Thickness standard」.
- When the measured value results in largely off the 「Thickness standard」 please try again 「Calibration standard」 from the beginning.
- ※ After performing Calibration standard , the previous 「Calibration standard value」 is deleted, and the last entry of 「Calibration standard value」 is stored.

(6) Zeroing — in special cases —

- ◎ In case of being painted as shown with multi-layers on the substrate there may be needs to measure thicknesses of each layer. For example, measuring only the thickness of the 4th layer please zero as an assumed 「Zero point」 at the surface of the 3rd layer stacked on the substrate and take 「Zeroing」, 「Calibration standard」 as the aforementioned (3), (4).



◆ Releasing of special-case zeroing

When zeroing again on the substrate after having finished the above measurements and if the combined thickness of 3 coating layers from 1st to 3rd exceeds $50\mu\text{m}$, please zero the meter on the following procedures. If the thickness of 3 combined layers is below $50\mu\text{m}$, take the same procedure as usual zeroing to release.

- Prepare the identical material and shape to a measuring object.
(This is designated as a 「Zero plate」.)

Press **ZERO** key.

The buzzer beeps.

CAL key changes to one data “deletion” function.



【ZERO Cal.】

1. Measure subst
-rate several
times.

2. press **ZERO** key.

Press the probe to the Zero plate.

The buzzer beeps, beeps, beeps 3 times.



OFFSET.

To continue,
press **ZREO** twice.

Press **ZERO** key.
The buzzer beeps.



Press **ZERO** key again.
The buzzer beeps.



【ZERO Cal.】

1. Measure subst
-rate several
times.
2. press **ZERO** key.

Press the probe to the Zero plate.
The buzzer beeps.



ZERO cal. (Fe)

1

μm

Cal. No. 1

Zeroing is in process.

The measuring object is set for ferrous metal substrate.

Measured a mean value

When the measured value results in largely off the "0", press **CAL** + **▼** key to delete the latest data out of measured values. It indicates "—" to delete all data.

Remove the probe from 「Zero plate」.



After pressing certain times or 20 times,
press **ZERO** key.




- Repeat a measuring processes, 1~20 times by pressing the probe to the 「Zero plate」.
(A mean value is displayed whenever a probe is pressed)

- ◆ When a measuring process reaches the 20th time, the buzzer beeps, beeps 2 times and afterward new entry is no more accepted.

The buzzer beeps.

It stops the “deletion” function of **CAL** key.



The reading **[ZERO cal.]** in the upper left disappears. Zeroing completed and the main unit becomes possible to take measuring and adjusting operations.

Data is stored in 「Cal. No. 1」 and 「F」 is displayed. (refer to page 7)

- Press the probe to the 「Zero plate」 several times and make sure the measuring result indicates in the neighborhood of “0”.
When the measured value results in largely off “0”, please try again zeroing from the beginning.
There is a case when calibration is not correctly made.
- “LLLL” displayed on the screen during a time of zeroing means that the calibration point heavily deviates from the standard.
Please make sure that the metal substrate is not processed with other materials such as plating and repeat the zeroing until a stable in the neighborhood of “0” is obtained.
- ※ After performing Zeroing, the previous 「Zeroing value」 is deleted, and the last entry of 「Zeroing value」 is stored.

(7) 2-point calibration in case it is difficult to perform 「Zeroing」

When it is difficult to adjust 「Zeroing」 in a usual method on a rough surface such as the Blast steel plate, it is effective also to adjust by using 「two pieces of different thickness of the Thicknesses standard」.



Caution

It is not possible to use both this calibration method and other calibration ones together, or mixing them together.

Should were the methods taken, measuring results could be the wrong values.

- Prepare the same blast-steel-plate in material as the objective base and two pieces of different thicknesses of the Thickness standards.

Please choose the suitable difference of thickness standards from the list below.

Predicting film thickness	Difference of thickness standard
~49.9 μm	10 μm or over
50.0~99.9 μm	25 μm or over
100.0~499.9 μm	50 μm or over
500~999 μm	199 μm or over
1.0~2.5 mm	0.5 mm or over

Press and hold the **ZERO** key for 3 seconds.

The buzzer beeps.



CAL key changes to one data “deletion” function.

【2-foil' s cal】

Measure thinner foil on metal several times.

Afterward, press **ZERO** key.

Stack the thinner 「Thickness standard」 on the substrate and press the probe on it.

The buzzer beeps whenever pressing the probe.



【 2-f. c. 】 (Fe)

27

μm

Cal. No. 1

2-foil calibration in process.


The measuring object is set for ferrous metal substrate.

Measured a mean value


When the measured value results in largely off the “Thickness standard”, press **CAL** + **▼** key to delete the latest data out of measured values. It indicates “—” to delete all data.

After pressing certain times or 20 times, press **ZERO** key.


The buzzer beeps, beeps 2 times.



A press of **▲** or **▼** key makes the buzzer beep and a mean value to the last measurement appears on the reading.



Adjust the reading value to the Thickness standard (in this case, 25 μ m) by pressing **▲** or **▼** key.



Pressing **▲** key increases the reading value.

Pressing **▼** key decreases the reading value.
(Press and holding key turns to fast forwarding.)

After adjusting the reading value to the Thickness standard, press **ZERO** key.
The buzzer beeps.



- Repeat a measuring processes, 1~20 times by pressing the probe to the thinner 「Thickness standard」.
(A mean value is displayed whenever a probe is pressed)
- ◆ When a measuring process reaches the 20th time, the buzzer beeps, beeps 2 times and afterward new entry is no more accepted.

【2-foil' s cal】
 Measure thicker foil on metal several times.
 Afterward, press **ZERO** key.

Stack the thicker 「Thickness standard」 on the substrate and press the probe on it.

The buzzer beeps whenever pressing the probe.



【 2-f. c. 】 (Fe)
 198
 μ m
 Cal. No. 1

Measured a mean value
 When the measured value results in largely off the "Thickness standard", press **CAL** + **▼** key to delete the latest data out of measured values. It indicates "—" to delete all data.

After pressing certain times or 20 times, press **ZERO** key.

The buzzer beeps, beeps 2 times.

- Repeat a measuring processes, 1~20 times by pressing the probe to the thicker 「Thickness standard」. (A mean value is displayed whenever a probe is pressed)

- ◆ When a measuring process reaches the 20th time, the buzzer beeps, beeps 2 times and afterward new entry is no more accepted.





【2-foil' s cal】
 Use **▲** or **▼**, to set foil thickness.
 Then, ready for measure.


A press of **▲** or **▼** key makes the buzzer beep and a mean value to the last measurement appears on the reading.




【 2-f. c. 】 (Fe)
 198
 μ m
 Cal. No. 1

Mean value


Adjust the reading value to the Thickness standard (in this case, 200 μ m)
by pressing  or  key.




Pressing  key increases the reading value.

Pressing  key decreases the reading value.
(Press and holding key turns to fast forwarding.)


Adjust the reading value to the Thickness standard.

After adjusting the reading value to the Thickness standard,
press  key.
Then the buzzer beeps, beeps, beeps 3 times.



This is on display for about 0.5 seconds.

The buzzer beeps.



This is a measuring mode.

Data is stored in 「Cal. No. 1」 and 「F」 is displayed.
(refer to page 7)

- It is correct that numerical values measured by pressing the probe a few times to the 「Thickness standard」 on the 「Zero plate」 indicates the thickness in the neighborhood of the 「Thickness standard」.
Take the procedure with each 2 sheets of the「Thickness standard」.
- When the measured value results in largely off the 「Thickness standard」 please try again 「2-foils calibration」 from the beginning.
- ※ After performing 2-foils calibration, the previous 「Calibration value」 is deleted, and the last entry of 「2-foils calibration value」 is stored.

(8) How to delete calibration

Take the following procedures to delete calibration when the reading on the screen is locked or after batteries replaced or when it becomes impossible to process 「Zeroing」, 「Calibration Standard」(CAL).


- ※ This operation procedures are taken when SWT-7200IV is faulty.
If “All cal. → ▲” is mistakenly selected, be careful that adjusted values of all calibration data are deleted.
- ※ When a store place is full , adjust a new data with the old data kept in th e place.
Automatically the old data is deleted and the new data is stored.

《Collective deletion》

- Delete collectively all adjustec values of all calibration data.

Hold **ZERO** key and press **▼** key.


The buzzer beeps, beeps 2 times.




- ※ When interrupting deletion, press **CANCEL** key.

Press **▲** key.

The buzzer beeps, beeps 2 times.



Deletion of calibration data is over and the buzzer beeps, beeps 2 times.




The last measured substrate and value are displayed.

It becomes possible to take measurements and adjustment procedures of this main unit.


After deleting, take 「Zeroing」, 「Calibration standard」 procedures proceeding to measuring.

《Selective deletion》


- Delete adjusted value of calibration data being selected now.
Display calibration data to be deleted. (refer to page 12)




Hold **ZERO** key and press **▼** key.
The buzzer beeps, beeps 2 times.



Press **▼** key.
The buzzer beeps, beeps 2 times.



Deletion of calibration data is over and
the buzzer beeps, beeps 2 times.



※ When interrupting deletion, press **CANCEL** key.

The last measured substrate and value are displayed.


It becomes possible to take measurements and
adjustment procedures of this main unit.

After deleting, take 「Zeroing」, 「Calibration standard」
procedures proceeding to measuring.

Measuring

! Hang the meter through a strap over your wrist never to drop it.


When pressing the probe against the object with Power ON, the buzzer beeps.



Each time a probe is pressed to an object the buzzer beeps and the measuring result is displayed.


◆ Measuring of Auto-selection by 「SFN-325」

- (1) Ferrous substrate measuring of film thickness at Fe mode.
- (2) Non-ferrous substrate measuring of film thickness at NFe mode.
- (3) Ferrous on Non-ferrous layered substrate measuring at Fe mode regardless of Fe thickness.



(4) Non-ferrous on ferrous layered substrate

- (4-1) Layered thickness Non-Ferrous and Film, 3.0 mm or less[※] measure thickness of layered Non-Ferrous and Film in Fe mode.
- (4-2) Layered thickness Non-Ferrous and Film, 3.5 mm or over[※] measure Film thickness in NFe mode.



Note:

- “HHHH” is displayed in a between area of 2 different layers and when special metals unidentified by Auto-selection.
- In case of adjusting by 「Calibration standard」 on Fe-substrate, 「Calibration standard」foils made of Non-Ferrous metals such as BeCu can be used.
- In case substrates are not identified by Auto-selection mode, change to exclusive mode by 『corresponding mode to a metal substrate』.



In case of an example of (4-1), thickness of Film only can be measured at 「Non-Ferrous」 exclusive mode.

※ They may vary in compositions, characteristics, thicknesses of materials.

Function setting

(1) Setting of Non-Interrupt Measurement mode

As illustrated on the right figure, this mode is used when taking non-interrupt measurements for painting surfaces etc. Film thickness values are taken/displayed while press/holding probe on the object.



A measured value is held (displayed) when pressing a probe at standard mode, but in Non-Interrupt Measurement mode measured values are taken/displayed about every 0.5 seconds interval while pressing a probe.


Hold **ZERO** key and press **▲** key.

The buzzer beeps, beeps 2 times.



This main unit has turned into 「Non-Interrupt Measurement mode」.

Data can be successively measured about 0.5 second intervals and the data is displayed with a beeping sound.



Reaching to a measurable distance, the probe indicates the distance/thickness at the spot.

Display of measured values (displayed successively each 0.5 second interval).

※ The Non-Interrupt function is stored when switching Power to OFF.

To return to the beginning, take the procedure of “Returning to the beginning” listed on the following page.




Caution

The moving measuring method at “Non-Interrupt Measuring Mode” may damage the measuring surface or the probe tip because of frictions made by sliding the probe on the surface.
Please try fewer to take this method to minimize the frictions.

《Returning to the beginning》


To return 「Non-Interrupt Measurement mode」 to the beginning take the same procedures as at the initial setting.

Hold **ZERO** key and press  key.

The buzzer beeps, beeps 2 times.



「Non-Interrupt Measurement mode」 has been released and returned to the beginning.



Measured values are stored until a next measurement is taken.

(2) Setting of resolutions


The reading values up to 500 μm can be switched in resolutions as below.

It is possible to read resolution measurement results by the 0.1 μm unit in the thickness of (0~400 μm), and by the 0.5 μm unit in the thickness of (400~500 μm).

- Switch Power to OFF when Power is ON.

Hold **CAL** key and press **①** key for 3 seconds or over.

The buzzer beeps, beeps 2 times.



Displayed :

0~400 μm by the 0.1 μm unit,

400~500 μm by the 0.5 μm unit.

- ※ This function is not released even if the Power source is switched to OFF.

When returning, take the operation procedures of “Returning to the beginning” as below.


《Returning to the beginning》

To return 「0.1 μm , 0.5 μm 」 displayed resolutions to the beginning, take the same procedures as the above.

- Switch Power to OFF when Power is ON.

Hold **CAL** key and press **①** key for 3 seconds or over.

The buzzer beeps, beeps 2 times.





No display under a decimal place.

(The data is rounded off to nearest whole digit.)

(3) Setting of units

This main unit is equipped with a function converting the unit to 「mil」.


- Switch Power to OFF when Power is ON.
- Press and hold  key for 10 seconds or over until the buzzer beeps, beeps 2 times.




- ※ This function is not released even if the Power source is switched to OFF.
When returning, take the operation procedures of “Returning to the beginning” as below.

《Returning to the beginning》

To return 「mil」 unit to the beginning, take the same procedures as the above.


- Switch Power to OFF when Power is ON.
- Press and hold  key for 10 seconds or over until the buzzer beeps, beeps 2 times.



(4) Setting of Auto-Power-OFF function

When no entry of key operations and measuring procedures for 3 minutes, the main unit switches automatically to OFF to save battery. This function can be released by the following operations.

No entry for 3 minutes lasts, and then the buzzer beeps.



The message is displayed for about 5 seconds.


The buzzer beeps, and the main unit is switched to OFF.

《To Disable Auto-Power-OFF function》

- Switch Power to OFF when Power is ON.

Hold  key and press  key for 5 seconds or over.


The buzzer beeps, beeps 2 times.



It indicates 5 seconds.



It returns to a measurable mode.


Power switches to OFF when  key is pressed.

- ※ This function is not released even if the Power source is switched to OFF.
To enable it, take the operation procedures of “To Enable Auto-Power-OFF function”.


《To Enable Auto-Power-OFF function》

- Switch Power to OFF when Power is ON.

Hold  key and press  key for 5 seconds or over.
The buzzer beeps., beeps 2 times.



It indicates 5 seconds.



It returns to a measurable mode.
Auto-Power-OFF function can be functioned.

When no entry of key operations and measuring procedures lasts about for 3 minutes, the buzzer beeps and the power is switched to OFF.

- ※ This function is not released even if the Power source is switched to OFF.
To disable it, take the operation procedures of “To Disable Auto-Power-OFF function”.


(5) Setting of corresponding mode to substrate with SFN-325 probe

When the SFN-325 probe is connected, the main unit automatically select a substrate for measuring objects, but in addition to the Auto-selection mode 『Fe substrate exclusive mode』, 『NFe substrate exclusive mode』 are ready to use.

In case it is not possible to identify the substrate by Auto-selection mode, change the mode on the following steps to take measurements with procedure as shown below.


- ※ When on Ex-factory, the unit is set to 「AUTO mode」.
- ※ This function is effective only when 「SFN-325」 probe is connected.
- ※ This finction is kept live even if the Power is switched to OFF.

【EX-factory setting】




Displays of Ferrous/Nonferrous Auto-selection mode are displayed by one of (AUTO), (Fe), (NFe) respectively.

Press and hold **CAL** key for 3 seconds or over.
The buzzer beeps, beeps 2 times.



When moving to a Fe substrate exclusive mode, **Fe** is displayed.

Press and hold **CAL** key for 3 seconds or over.
The buzzer beeps, beeps 2 times.



When moving to a NFe substrate exclusive mode, **NFe** is displayed.


By press and holding **CAL** key for 3 seconds or over,
it switches: AUTO → Fe → NFe → AUTO → Fe

(6) Setting of Backlight


The LCD of this unit has a backlight function.

The backlight can be used at the place which is dark and difficult to read messages on display.

《Lighting the Backlight》


Press and hold  key for 3 seconds or over.

The buzzer beeps, beeps 2 times
and the backlight goes on.




It is shown when the backlight is ON.

《Lighting out the Backlight》

Press and hold  key for 3 seconds or over.

The buzzer beeps, beeps 2 times
and the backlight goes off.



The mark and the backlight go off.


※ This function is kept even if Power source switched to OFF.

Setting of High/Low limit values


To judge quickly if the coated film thickness of a product stays within a range of thicknesses corresponding to management standards and controls, it is necessary to set high/low limits beforehand and if the numerical value on display exceeds the limits, the number flashes and emits a warning sound.

※ A set of both limit values can be set to a 「Cal. No. 」 (Calibration curve).

(1) Setting of High limit value



Press **H/L** key.
The buzzer beeps.




Press **▲** or **▼** key to enter a High limit value into the flashing column 「---」.

Press **H/L** key.
The buzzer beeps to set the High limit value.



Then setting of a Low limit value follows.



A High limit value flashes.


Data for setting High/Low limit values is displayed.

A High limit value flashes.

Note: When no High limit value setting is needed, press **H/L** key without pressing **▲**, **▼** key. Flashing 「H: --- μm」 stops and it moves a next to set Low limit value.


(2) Setting of Low limit value

(following a High limit value setting without interruption)




A Low limit value flashes.

Press or key to enter a Low limit value to the flashing column 「---」.



A Low limit value flashes.

Press key.
The buzzer beeps.



The flashing Low limit value stops and the High/Low limit values are set. It becomes possible to take measurements and adjustments.

Note: When no Low limit value setting is needed, press key without pressing , key. Flashing 「L: --- μm」 stops and a High limit value only is set, and it becomes possible to take measurements and adjustments.

(3) Deletion of set High/Low limit values.

Select a 「Cal. No. 」 (Calibration curve) storing limit values to be deleted.

(Fe)		
125		
μm		
Cal. No. 8 F		
Lmt.	H: 150 μm	L: 100 μm

Hold **H/L** key and press **DATA ERASE** key.
The buzzer beeps, beeps 2 times.



ERASE? HI & LO Limits.

Press **DATA ERASE** key.
The buzzer beeps, beeps 2 times.




(Fe)		
125		
μm		
Cal. No. 8 F		

A set limited value is deleted and at the same time a displayed column of the limit value also disappears.

Measurements with High/Low limit values


(1) When measured value within a range of limit value (including a setting value)

The buzzer beeps and indicates the measured value.




(2) When measured value over a High limit value

The buzzer 「beeps」 「beep」 「beep」, 「beep」 「beep」 「beep」 2 times with 3 successive sounds.



(3) When measured value below a Low limit value

The buzzer 「beeps」 「beep」 「beep」, 「beep」 「beep」 「beep」 2 times with 3 successive sounds.



Storing of measured data

SWT-7200IV can store Max. 20,000 data.


Places to store are listed as below.

Sections: A section stores 10 data. Each 「Data storing position」 within a section has each independent number.

Blocks: A block contains 10 「Sections」. Each 「Section」 within a block has each independent number.

Groups: A group contains 20 「Blocks」. Each 「Block」 within a group has each independent number.
SWT-7200IV has 10 groups.

■ Data-Memory information displayed. on LCD



※ When delivered at EX-Factory. The indications are as follows.

memNo.	1	1	1	s: 10 :	1
--------	---	---	---	---------	---

The displays of memory position of (Sub-screen)

	MEMORY
	G : 1
	B : 1
	S : 1
	Size : 10
	C.P. : 1

A Group No. is displayed.

A Block No. is displayed.

A Section No. is displayed.

The number of data stored in a section is displayed.


A Data storing position within a section is displayed.

(1) Select a Data storing place

- For operation example, settings are made as follows:
Group No. 「3」, Block No. 「12」, Section No. 「1」, Data storing number per section 「8」.




Press **MEM. SEL.** key.
The buzzer beeps.



A Group No. flashes.

Press **▲** or **▼** key.
Select a Group No. 「3」.






A Group No. flashes.


Press **MEM. SEL.** key.
The buzzer beeps.




※ A Group No. 「3」 is set.
Then moving on to setting a Block No.




Press  or  key to select a Block No. 「12」.





Press  key.
The buzzer beeps.




※ A Block No. 「12」 is set.
Then moving on to setting a Section No.



Press  or  key to select a Section No. 「1」.

(In this example, as Section No. is 「1」 So it moves on to the next as it is)





A Section No. flashes.


Press **MEM. SEL** key.

The buzzer beeps.




※ A Section No. 「1」 is set.

Then moving on to setting a Data storing number per section.



A Data storing number flashes.

Press **▲** or **▼** key to select a Data storing number 「8」.




A Data storing number flashes.

Press **MEM. SEL** key.

The buzzer beeps.



- ※ A Data storing number 「8」 is set.
Lastly, specify a Data storing position within a Section.




In this example, start storing from a Data storing position 「1」 within a Section.

A Data storing position flashes.

Press or key to select a Data storing position 「1」.


(In this example, as Data storing position is 「1」. So it moves on to next as it is)



A Data storing position flashes.

Press key.*
The buzzer beeps.


※ Note:
Pressing twice key turns the screen to a state of 「Data is not stored」 and then 「Data storing place」 disappears on the screen.
To store measured data press key 6 times successively so that it turn to a state of 「Data storing place is displayed and all setting data do not flash」.



Flashing of all numbers stopped and setting of 「Data storing place」 has completed.
It becomes possible to take measurements and adjustments.

(2) Keep data from being stored

※ It is in a state of 「Storing data」.




The calculator screen displays the following information:

- Top right: (AUTO)
- Below (AUTO): a horizontal line
- Below the line: μ m
- Below μ m: a box containing "Cal. No. 1 F"
- Bottom row: a table with the following cells: memNo., 3, 12, 1, S:, 8:, 1

← A state of Non-Flashing of all items.

Press key.
The buzzer beeps.




The calculator screen displays the following information:

- Top right: (AUTO)
- Below (AUTO): a horizontal line
- Below the line: μ m
- Below μ m: a box containing "Cal. No. 1 F"

← The screen disappears and turns to a state of 「Data is not stored」.


Measurements in storing data

- ※ Select a place to store data as described in 「(1) Select a Data storing place」 at page 42.
- For operation example, store 8 pcs of measuring data in order from a Data Stroing position 「1」 in a Group No. 「3」, a Block No. 「12」, a Section No. 「1」.



- ※ According to explanations on page 11, quickly press a probe to a measuring object.

A measurement is taken.
The buzzer beeps.




A measured result is displayed.

A data measured now is stored in a Data storing position 「1」.
(a number advances by one each time measured)

⋮

- When the measurement progresses and the data is stored in the last end of a Section No. 「1」 in the 8th measurement, the buzzer beeps, beeps 2 times and warnig that it advances to 「New Section」 in the following measurement.



A screen when the 8th measurement was finished.

A number in a storing place advances to 「8」.
8 pieces of data measured are stored in the places
from the numbers of 「1」 to 「8」.

A measurement is taken.
The buzzer beeps.



		(Fe)	
		106	
		μm	
Cal. No. 1 F			
memNo.	3	12	2
		S: 8:	1

The 9th measured result is displayed.
The 9th measured data is stored in a Data storing position 「1」 in a Section No. 「2」.

A Data storing position returns to 「1」.

A Section No. advances by one to 「2」.

⋮

- When the measurement progresses and the data is stored in the last end of a Block No. 「12」, a Section No. 「10」, the buzzer beeps, beeps 2 times and warnig that it advances to 「New Block」 in the following measurement.

		(Fe)	
		104	
		μm	
Cal. No. 1 F			
memNo.	3	12	10
		S: 8:	8

This is a screen when the data is stored in the last end of a Block No. 「12」, a Section No. 「10」.

A Data storing position 「8」 is displayed.

A measurement is taken.
The buzzer beeps.



		(Fe)	
		104	
		μm	
Cal. No. 1 F			
memNo.	3	13	1
		S: 8:	1

A measured result is displayed.
This measuring data is stored in a Data storing position 「1」 of a Block No. 「13」, a Section No. 「1」.

A Data storing position returns to 「1」.

A Section No. returns to 「1」.

A Block No. advances by one to 「13」.

※ In a Block No. 「12」, 8 data/section × 10 section, total 80 of measuring data are stored.

⋮

- When the measurement progresses and the data is stored in the last end of a Block No. 「20」, a Section No. 「10」, the buzzer beeps, beeps 2 times and warnig that it advances to 「New Group」 in the following measurement.

		(Fe)	
		104	
		μ m	
Cal. No. 1 F			
memNo.	3	20	10 S: 8: 8

This is a screen when the data is stored in the last end of a Block No. 「20」, a Section No. 「10」.

A Data storing position 「8」 is displayed.

A measurement is taken.
The buzzer beeps.



		(Fe)	
		107	
		μ m	
Cal. No. 1 F			
memNo.	4	1	1 S: 8: 1

A measured result is displayed.

This measuring data is stored in a Data storing position 「1」 of a Group No. 「4」, a Block No. 「1」, a Section No. 「1」.

A Data storing position returns to 「1」.

A Section No. returns to 「1」.

A Block No. returns to 「1」.

A Group No. advances by one to 「4」.

※ In a Group No. 「3」, 8 data/section × 10 section/block × 9 block, total 720 of measuring data are stored.

※ It becomes 9 block as started storing from 12 block.

⋮

- When the measurement progresses and the data is stored in the last end of a Group No. 「10」, a Block No. 「20」, a Section No. 「10」, the buzzer beeps, beeps 2 times and warnig that no more data can be stored.

		(Fe)	
		101	
		μ m	
Cal. No. 1 F			
memNo.	10	20	10 S: 8: 8

This is a screen when the data is stored in the last end of a Group No. 「10」, a Block No. 「20」, a Section No. 「10」.


A Data storing position 「8」 is displayed.

A measurement is taken.
The buzzer beeps.

※ This time the measuring data is not displayed.




The buzzer beep, beeps.



Storing data has been completed.

- It is possible to continue measurements , but measuring data only is displayed.

A measurement is taken.
The buzzer beeps.




← A measured result is displayed.

← The screen disappears and turns to a state of 「Data is not stored」.

Storing of measured data at Non-Interrupt Measurement Mode

When this unit is set at 「Storing of measured data」 and measurements are taken at 「Non-Interrupt Measurement Mode」, it is capable of storing data on the following procedures.

- Select a place to store data as described in 「(1) Select a Data storing place」 at page 42.
- Start Non-Interrupt measuring.




※ Only 「1 data」 is stored when the transfer key is released.

Three kinds of measuring methods in case of 「No memory space」

(1) Keep on measuring

- Measuring.

The buzzer beeps.



A measured result is displayed.




Caution


Measuring can be continued but data can not be stored.

(2) Looking for an empty storing place

- Interrupt measuring.
- Select a place to store data as described in 「(1) Select a Data storing place」 at page 42.



In case data is stored in a selected place, the value is displayed.



In case a selected place is unoccupied, 「—」 mark is displayed.




Caution

Depending on measurement quantities, 5~6 blocks (500~600 : storing quantity) recommended for selecting as empty places to store successively.

Measuring is resumed.

The buzzer beeps.



A measured value is displayed.

A measured value is stored and advances the number of a Data storing position by one.

(3) Deletion of unnecessary data


- Delete an unnecessary data in a storing place and store there new data which is to be taken.
- Delete all of unnecessary data afterward, referring to each kind of deletion methods.
- Resume 「Measurements while storing data」 after deleting data.

Deletion of data

(1) Deletion of one data


- ※ Data inadvertently by pressing a probe against objectives, poor and unstable pressing on objects and erroneous data which are stored can be deleted.

Erroneous value is displayed.



Press **DATA ERASE** key.

The buzzer beeps.




「ERASE?」 appears on the screen and flashes.

The measured value flashes.

Press **DATA ERASE** key.

The buzzer beeps.



The measured value is deleted.

The previous stored data is displayed.

A Data storing position returns by one.

When data storing places are running short and sorted data is no more necessary, it is possible to delete all data collectively and delete data of each storing place.

(2) Deletion of all data

※ 『all data』 stored are collectively deleted.

		(Fe)	
		302	
Cal. No. 1 F		μ m	
memNo.	3	1 2	6 S: 10: 3

Press **MEM. CLEAR** key.
The buzzer beeps, beeps 2 times.



Caution

This operation can not be activated when data column of data storing place is not displayed. When it is not displayed, press **MEM. SEL** key 6 times to activate the column with all the numbers displayed.



<p>ERASE ?</p> <p>all data in; all memory.</p>

Press **MEM. CLEAR** key.
The buzzer beeps, beeps 2 times.



<p>ERASE</p> <p>all data in; all memory.</p>

All stored data are deleted.

The buzzer beeps.




		(Fe)	
		—	
Cal. No. 1 F		μ m	
memNo.	1	1 1	1 S: 10: 1


「—」 mark is displayed.

In the Data storing information, a Data storing number per section 「10」 and all others are 「1」.


(3) Deletion of group data

- ※ Data stored in arbitrary group with Group No. 1~10 is deleted.
- For operation example, data stored in a Group No. 「5」 is deleted.




 **Caution**
 This operation can not be activated when data column of data storing place is not displayed. When it is not displayed, press **MEM. SEL** key 6 times to activate the column with all the numbers displayed.

Press **MEM. CLEAR** key.
 The buzzer beeps, beeps 2 times.






Press **MEM. SEL** key.
 The buzzer beeps.




The Data storing information is displayed.

A Group No. flashes.



Press  or  key to adjust to a Group No. in which to delete data.






Adjust to a Group No. 「5」.



Press **MEM. CLEAR** key.

The buzzer beeps, beeps 2 times.



Press **MEM. CLEAR** key.

The buzzer beeps.



「—」 mark is displayed.

The Data storing information turn as follows:

Group No. 「5」

Block No. 「1」

Section No. 「1」


Data storing number per section 「10」

Data storing position 「1」.

(4) Deletion of block data


※ Data stored in arbitrary block with Block No. 1~20 is deleted.

● For operation example, data stored in a Group No. 「1」, a Block No. 「12」 is deleted.




Press **MEM. CLEAR** key.

The buzzer beeps, beeps 2 times.



Press **MEM. SEL** key.

The buzzer beeps.




Caution
 This operation can not be activated when data column of data storing place is not displayed. When it is not displayed, press **MEM. SEL** key 6 times to activate the column with all the numbers displayed.

A Group No. flashes.

Press **▲** or **▼** key to adjust to a Group No. where there is a block to be aimed at.






Adjust to a Group No. 「1」.


Press **MEM. SEL** key.

The buzzer beeps.



A Group No. is set at 「1」, and a Block No. flashes.


Press **▲** or **▼** key to adjust to a Block No. to be aimed at.



Adjust to a Block No. 「12」.

Press **MEM. CLEAR** key.

The buzzer beeps, beeps 2 times.



Press **MEM. CLEAR** key.

The buzzer beeps.



ERASE

all data in;
B = 12.
【 in G = 1 】



(Fe)

—

μ m

Cal. No. 1 F

memNo.	1	12	1	S:	10:	1
--------	---	----	---	----	-----	---

「—」 mark is displayed.

The Data storing information turn as follows:

Group No. 「1」

Block No. 「12」

Section No. 「1」

Data storing number per section 「10」

Data storing position 「1」.

(5) Deletion of section data

※ Data stored in arbitrary section with Section No. 1~10 is deleted.

● For operation example, data stored in a Group No. 「3」, a Block No. 「7」, a Section No. 「5」 is deleted.

		(Fe)	
		403	
		μm	
Cal. No. 1 F			
memNo.	2	6	3 S: 10: 5

Press **MEM. CLEAR** key.

The buzzer beeps, beeps 2 times.




ERASE ?	
all data in; all memory.	

Press **MEM. SEL** key.

The buzzer beeps.



		(Fe)	
		403	
		μm	
Cal. No. 1 F			
memNo.	2	6	3 S: 10: 5

 **Caution**
This operation can not be activated when data column of data storing place is not displayed. When it is not displayed, press **MEM. SEL** key 6 times to activate the column with all the numbers displayed.

A Group No. flashes.

Press **▲** or **▼** key to adjust to a Group No. where there is a block to be aimed at.




		(Fe)	
		500	
		μm	
Cal. No. 1 F			
memNo.	3	6	3 S: 10: 5

Adjust to a Group No. 「3」.


Press **MEM. SEL** key.

The buzzer beeps.



A Group No. is set at 「3」, and a Block No. flashes.


Press **▲** or **▼** key to adjust to a Block No. where there is a section to be aimed at.



Adjust to a Block No. 「7」.

Press **MEM. SEL** key.


The buzzer beeps.



A Block No. is set at 「7」, and a Section No. flashes.

Press **▲** or **▼** key to adjust to a Section No. to be aimed at.






Adjust to a Section No. 「5」.



Press **MEM. CLEAR** key.

The buzzer beeps, beeps 2 times.



Press **MEM. CLEAR** key.

The buzzer beeps.



「—」 mark is displayed.

The Data storing information turn as follows:

Group No. 「3」

Block No. 「7」

Section No. 「5」

Data storing number per section 「10」

Data storing position 「1」.

Statistics (statistical calculation value of chosen data is displayed)

(1) Statistics of all data

				(Fe)
107				μ m
Cal. No. 1 F				
memNo.	1	2	5	S: 10: 10

The Data storing information is displayed.

Press **STATISTICS** key.

The buzzer beeps, beeps 2 times.



Statistics Calculation all data in; all memory. START ?

Press **STATISTICS** key.

The buzzer beeps, beeps 2 times.

(displayed as being under process of calculating)

The buzzer beeps.



VALUE : [ALL mem.]	
#-date :	1 5 0
Mean :	1 0 6 . 5
Median :	1 0 6 . 4
Max. :	1 0 8 . 1
Min. :	1 0 4 . 6
S.D. :	0 . 8

Press **STATISTICS** key.

The buzzer beeps.



				(Fe)
107				μ m
Cal. No. 1 F				
memNo.	1	2	5	S: 10: 10

Note:

If **STATISTICS** key is not pressed, this screen remains unchanged until Power switches off.

The screen returns to the state before statistical calculation.

(2) Statistics of group data

- ※ Statistical calculation is performed on the data stored in arbitrary group with Group No. 1~10.
- For operation example, Statistical calculation is performed on the data stored in a Group No. 「3」.

(Fe)				
107				
μm				
Cal. No. 1 F				
memNo.	1	2	5	S: 10: 10

The Data storing information is displayed.

Press **STATISTICS** key.

The buzzer beeps, beeps 2 times.



Statistics Calculation	
all data in; all memory.	
START ?	

Press **MEM. SEL** key.

The buzzer beeps.



(Fe)				
107				
μm				
Cal. No. 1 F				
memNo.	1	2	5	S: 10: 10

A Group No. flashes.

Press **▲** or **▼** key to adjust to a Group No. in which to calculate statistics.



(Fe)				
107				
μm				
Cal. No. 1 F				
memNo.	3	2	5	S: 10: 10

Adjust to a Group No. 「3」.

Press **STATISTICS** key while a Group No. is flashing.
 The buzzer beeps, beeps 2 times.



Statistics
 Calculation

all data in;
 G = 3.

START ?

Press **STATISTICS** key.
 The buzzer beeps, beeps 2 times.
 (displayed as being under process of calculating)
 The buzzer beeps.



VALUE : [G = 3]

#-date :		1 5 0
Mean :		1 0 6 . 5
Median :		1 0 6 . 4
Max. :		1 0 8 . 1
Min. :		1 0 4 . 6
S. D. :		0 . 8

Press **STATISTICS** key.
 The buzzer beeps.

Note:
 If **STATISTICS** key is not pressed, this screen remains unchanged until Power switches off.



(Fe)

107

μ m

Cal. No. 1 F


memNo.	1	2	5	S: 10: 10
--------	---	---	---	-----------

The screen returns to the state before statistical calculation.

(3) Statistics of block data

※ Statistical calculation is performed on the data stored in arbitrary block with Block No. 1~20.


● For operation example, Statistical calculation is performed on the data stored in a Group No. 「1」, a Block No. 「14」.



The Data storing information is displayed.


Press **STATISTICS** key.

The buzzer beeps, beeps 2 times.




Press **MEM. SEL** key.

The buzzer beeps.



A Group No. flashes.


Press **▲** or **▼** key to adjust to a Group No. where there is a block to calculate statistics.



Adjust to a Group No. 「1」.


Press **MEM. SEL** key.

The buzzer beeps.



A Group No. is set at 「1」, and a Block No. flashes.


Press **▲** or **▼** key to adjust to a Block No. in which to calculate statistics.



Adjust to a Block No. 「14」.

Press **STATISTICS** key while a Block No. is flashing.

The buzzer beeps, beeps 2 times.



Press **STATISTICS** key.

The buzzer beeps, beeps 2 times.

(displayed as being under process of calculating)

The buzzer beeps.



VALUE : [B = 14]	
[in G = 1]	
#-date :	5 0
Mean :	1 0 6 . 2
Median :	1 0 6 . 1
Max. :	1 0 7 . 5
Min. :	1 0 4 . 6
S. D. :	0 . 7

Press key.
The buzzer beeps.



(Fe)				
107				
μ m				
Cal. No. 1 F				
memNo.	1	2	5	S: 10: 10

Note:


If key is not pressed, this screen remains unchanged until Power switches off.

The screen returns to the state before statistical calculation.

(4) Statistics of section data

※ Statistical calculation is performed on the data stored in arbitrary section with Section No. 1~10.


- For operation example, Statistical calculation is performed on the data stored in a Group No. 「5」, a Block No. 「2」, a Section No. 「1」.



The Data storing information is displayed.


Press **STATISTICS** key.

The buzzer beeps, beeps 2 times.




Press **MEM. SEL** key.

The buzzer beeps.



A Group No. flashes.

Press **▲** or **▼** key to adjust to a Group No. where there is a block to calculate statistics.



Adjust to a Group No. 「5」.

Press **MEM. SEL** key.

The buzzer beeps.



		(Fe)
107		
		μ m
Cal. No. 1 F		
memNo.	5	5 S: 10: 10

A Group No. is set at 「5」, and a Block No. flashes.

Press **▲** or **▼** key to adjust to a Block No. where there is a section to calculate statistics.



		(Fe)
107		
		μ m
Cal. No. 1 F		
memNo.	5	2 S: 10: 10

Adjust to a Block No. 「2」.

Press **MEM. SEL** key.

The buzzer beeps.




		(Fe)
107		
		μ m
Cal. No. 1 F		
memNo.	5	2 5 S: 10: 10

A Block No. is set at 「2」, and a Section No. flashes.


Press **▲** or **▼** key to adjust to a Section No. in which to calculate statistics.






Adjust to a Section No. 「1」.

Press **STATISTICS** key while a Section No. is flashing.
The buzzer beeps, beeps 2 times.




Press **STATISTICS** key.
The buzzer beeps.



Press **STATISTICS** key.
The buzzer beeps.

Note:

If **STATISTICS** key is not pressed, this screen remains unchanged until Power switches off.



The screen returns to the state before statistical calculation.

Transferring data – USB –


Transfer data to a PC (personal computer) by using a USB cable.

Download the USB transfer driver from the included CD or our website.

- ※ Data is not transferred when the main unit is set to 「Non-Interrupt Measuring mode」.
Make sure beforehand that this main unit is set to 「is set to Normal (hold) Measuring mode」.
- ※ Even when the unit of this instrument is set to the 「mil」, the data transferred to the Transfer software is displayed with the 「 μm 」 unit.


(1) Outright transferring measured data (Real time transfer)

- Prepare for a PC side.
- Connect a USB cable to a PC.




This is a USB cable connector.

Hook up a USB cable to USB cable connector and the other side to PC.



Press **COM. ENABLE** key.

The buzzer beeps.



Press **TRANSMIT** key.


The buzzer beeps.

Data is sent out each time a measurement is taken.




Caution


Pressing **COM. ENABLE** key without connecting USB cable, a warning 「USB cable un-connected」 is displayed.
 Press again **COM. ENABLE** key to delete the letters and connect USB cable.



(2) Interrupt transferring data



Press **COM. ENABLE** key.
 The buzzer beeps.




Data stops being transferred.


Transferring stored data – USB –

(1) Transfer of all data


- ※ Transferring all stored data.
- Prepare for a PC side.
- Connect a USB cable to a PC.



Press **COM. ENABLE** key.
The buzzer beeps.



Press **MEM. SEL** key.
The buzzer beeps, beeps 2 times.



Press **TRANSMIT** key.
The buzzer beeps, beeps 2 times.




USB mark is displayed.




Caution

Pressing **COM. ENABLE** key without connecting USB cable, a warning 「USB cable un-connected」 is displayed. Press again **COM. ENABLE** key to delete the letters and connect USB cable.




The buzzer beeps.



Transferring is completed, returning ns to the beginning.

(2) Transfer of group data


- ※ Data stored in arbitrary group with Group No. 1~10 is transferred.
- Prepare for a PC side.
- Connect a USB cable to a PC.
- For operation example, data stored in a Group No. 「3」 is transferred.



Press key.

The buzzer beeps.






USB mark is displayed.


Caution

Pressing **COM. ENABLE** key without connecting USB cable, a warning 「USB cable un-connected」 is displayed. Press again **COM. ENABLE** key to delete the letters and connect USB cable.

Press **MEM. SEL.** key.
The buzzer beeps, beeps 2 times.




Press **MEM. SEL.** key.
The buzzer beeps.



A Group No. flashes.

Press **▲** or **▼** key to adjust to a Group No. in which to transfer data.



Adjust to a Group No. 「3」.

Press **TRANSMIT** key while a Group No. is flashing.
The buzzer beeps, beeps 2 times.



TRANSMIT ?
all data in;
G = 3.

Press **TRANSMIT** key.
The buzzer beeps.



TRANSMITTING.
all data in;
G = 3.

The buzzer beeps.




(Fe)
101
 μ m
Cal. No. 1 F
memNo. 1 2 5 S: 10: 10

Transferring is completed, returning ns to the beginning.

(3) Transfer of block data


※ Data stored in arbitrary block with Block No. 1~20 is transferred.

- Prepare for a PC side.
- Connect a USB cable to a PC.
- For operation example, data stored in a Group No. 「4」, a Block No. 「7」 is transferred.



Press **COM. ENABLE** key.


The buzzer beeps.



USB mark is displayed.

Press **MEM. SEL.** key.

The buzzer beeps, beeps 2 times.



Press **MEM. SEL.** key.


The buzzer beeps.



Caution


Pressing **COM. ENABLE** key without connecting USB cable, a warning 「USB cable un-connected」 is displayed.

Press again **COM. ENABLE** key to delete the letters and connect USB cable.



A Group No. flashes.


Press or key to adjust to a Group No. where there is a block to transfer data.



Adjust to a Group No. 「4」.


Press key.

The buzzer beeps.



A Group No. is set at 「4」, and a Block No. flashes.

Press or key to adjust to a Block No. in which to transfer data.



Adjust to a Block No. 「7」.

Press **TRANSMIT** key while a Block No. is flashing.
The buzzer beeps, beeps 2 times.



TRANSMIT ?
all data in;
B = 7.
【 in G = 4 】

Press **TRANSMIT** key.
The buzzer beeps.



TRANSMITTING.
all data in;
B = 7.
【 in G = 4 】




(Fe)
101
 μ m
Cal. No. 1 F
memNo. 1 2 5 S: 10: 10

Transferring is completed, returning ns to the beginning.

(4) Transfer of section data


※ Data stored in arbitrary section with Section No. 1~10 is transferred.

- Prepare for a PC side.
- Connect a USB cable to a PC.
- For operation example, data stored in a Group No. 「5」, a Block No. 「8」, Section No. 「1」 is transferred.



Press **COM. ENABLE** key.


The buzzer beeps.



USB mark is displayed.


Press **MEM. SEL.** key.

The buzzer beeps, beeps 2 times.



Press **MEM. SEL.** key.

The buzzer beeps.




A Group No. flashes.



Caution

Pressing **COM. ENABLE** key without connecting USB cable, a warning 「USB cable un-connected」 is displayed. Press again **COM. ENABLE** key to delete the letters and connect USB cable.


Press  or  key to adjust to a Group No. where there is a block to transfer data.



Adjust to a Group No. 「5」.


Press  key.

The buzzer beeps.




A Group No. is set at 「5」, and a Block No. flashes.


Press  or  key to adjust to a Block No. where there is a section to transfer data.





Adjust to a Block No. 「8」.


Press  key.

The buzzer beeps.




A Block No. is set at 「8」, and a Section No. flashes.


Press  or  key to adjust to a Section No. in which to transfer data.



Adjust to a Section No. 「1」.



Press  key while a Section No. is flashing.

The buzzer beeps, beeps 2 times.



Press  key.

The buzzer beeps.



Transferring is completed, returning ns to the beginning.

Note to improve measuring accuracy

① Zero plate

Prepare the same material, thick and shape plate as the measuring object for Zeroing and Calibration standard (CAL). Different materials may not bring about correct measuring results.

※ As accessories to probe (option), “Zero plates” are **for testing purpose only**.

Select a most optimal zero plate to meet actually measuring objects. (Please refer to page 14)

② Thickness standard (foils)

Take Calibration standard (CAL) using a Thickness standard which is thicker or as thick as the measuring films.

※ Use of a Thickness standard with a deviant thickness may cause errors.

Replace worn-out or bent plates with new ones. In case non-accessorized plates are necessary (over 16 μm), contact a local sales office.

③ Quality of films to be measured

Magnetic metal contained in the films can correctly not be measured. In case of measuring elastic films, place a Thickness standard of 30~50 μm thick on the object and subtract the thickness from the measuring value to avoid errors to be caused by elastic dents.

④ Measurements of edges or angles

Magnetic fields in the neighborhood of the edges/the angles of a measuring object become uneven.

15~20mm closer part to the center of the object shall generally be measured.

Pay attention to protruded part, curved part or unexpectedly deformed part.

⑤ Measurements of rough faces

Roughness of a substrate, a measuring face affects measuring results.

Take a mean value by measuring several places at a time.

⑥ Measurements of stretched part on faces

In some case stretched, rolled part occurred on a substrate, which may cause measuring errors.

Take a mean value by measuring several places at a time.

⑦ Temperature

Operating temperature range is 0~40°C.











Especially, large temperature differences between a main unit and a probe causes measuring error.

⑧ Residual magnetism, stray magnetic fields

Pay attention to transportation method of electromagnets, residual magnetism on substrates or arc welding, those of which emit strong magnetic fields to cause measuring errors.

Trouble Shooting

Before contacting us please check with the following points.

Symptoms	Points to check	Measures to be taken
No response upon press of 「  」 key.	Are batteries worn out?	Replace them with new ones (2 ea.).
No response after replacing batteries and pressing a 「  」 key.	Something wrong inside a main unit.	Contact us for repair.
	Batteries is shorting.	They can be used for a while. Prepare for new batteries.
	Batteries have worn out.	Replace them with new ones.
	Out of batteries.	Replace them with new ones.
	Possibly pressing probe to object too soon after pressing 「  」 key.	Hold probe in air, keeping it away off measuring objects, metals during a time of “START UP ...” on screen.
	Press 「  」 key without connecting probe.	Press 「  」 key after being sure of connecting probe.


Symptoms	Points to check	Measures to be taken
<p>TROUBLE ! The probe may have trouble. Change it to the other one.</p> <p>《Power OFF》</p>	Something wrong with probe.	Contact us for repair.
<p>TROUBLE ! The probe and the main unit may have trouble. Repairing needed.</p> <p>《Power OFF》</p>	Something wrong with probe/ main unit.	Contact us for repair.
Data can not be stored in memory.	Is data stored in all memory?	Delete unnecessary data to make vacancies in memory.
	Is Measurement mode set to 『Non-Interrupt Measurement mode』?	Press 「TRANSMIT」 key and release it. Data is stored when releasing.
<p>USB cable un-connected</p>	Is USB cable connected correctly ?	Connect USB cable correctly.
Unable to transfer data.	<p>① Is USB cable connected correctly ?</p> <p>② Is PC side ready to operate ?</p>	<p>① Connect USB cable correctly.</p> <p>② (1) Install driver by our home page correctly. (2) Set Comport No.correctly.</p>
Sudden interruption of data transfer.	<p>① Does PC operate normally?</p> <p>② PC side is not faulty. → Something wrong with main unit.</p>	<p>① Check if something wrong with PC side.</p> <p>② Contact us for repair.</p>

Disclaimer

We are not liable for any damage to customers caused by the use or inability to use of this product (including built-in software and data).

Specifications

◆ Main unit

Items	Applications
Model name	Dual (Electromagnetic/Eddy current) type coating thickness meter SWT-7200IV
Display method	Graphic LCD (data/message), Backlight
Ranges	Depending on optional probes
Calibrations (CAL)	2-point calibration Zero: metal substrate calibration Calibration standard: metal substrate and thickness standard calibration
Additional functions	<ul style="list-style-type: none"> ① Switching measuring modes (hold/non-interrupt) ② Switching display resolutions (depending on a connecting probe) ③ Switching of units ④ Auto Power Off (about 3 min.), releasing and reactivating ⑤ Setting for exclusive substrate mode (only when SFN-325 probe is connected) ⑥ Backlight ⑦ Setting/storing of calibration curves: Max. 10 pcs ⑧ Upper/lower limit setting, alarm (setting by each calibration) ⑨ Collective/selective deletions of calibration values ⑩ Measuring data memory: 20,000 data ⑪ Statistics process, displays ⑫ Data output to PC (USB terminals) ⑬ Screen switching function (Main/Sub)
Keys	
Power	3V DC Dry Battery (LR6 × 2), Continuous operation hours about 25 hours [※] AC adaptor ※ Maximum (may vary depending on usage conditions)
Operating Temperature	0 ~ 40°C (Non-condensing)
Accessories	Dry battery, Carrying case, Hand strap cord, Inspection certificate, AC adaptor, USB cable, CD (Instruction manual, USB driver, etc.)
Option	For ferrous substrate probe (SFe), For nonferrous substrate probe (SNFe), Dual ferrous/nonferrous substrate probe (SFN-325),
Dimensions	72(W) × 30(H) × 156(D)mm
Weight	About 200g

◆ Probe (option)

Model	SFN-325	SFe-0. 6Pen	SFe-0. 6L
Measuring method	Dual (Electromagnetic/Eddy current) type (auto-selection for Fe/NFe)	Electromagnetic type	
Measuring range	Fe: 0~3. 00mm, NFe: 0~2. 50mm	0~600 μm	
Resolutions	1 μm: 0~999 μm 0. 01mm: 1. 00~3. 00mm (Fe) : 1. 00~2. 50mm (NFe) by switching 0. 1 μm: 0~400 μm 0. 5 μm: 400~500 μm	1 μm: 0~600 μm by switching 0. 1 μm: 0~400 μm 0. 5 μm: 400~500 μm	
Accuracies (to flat, smooth face)	0~100 μm: ±1 μm or ±2% of reading 101 μm~3. 00mm: ±2% (Fe) 101 μm~2. 50mm: ±2% (NFe)	0~100 μm: ±1 μm or ±2% of reading 101~600 μm: ±2%	
Probes	One point contact constant pressure typ V-cut about φ 15 × 51mm	One point contact constant pressure typ V-cut about φ 5.5 × 92.5mm	One point contact constant pressure typ about 8 × 13.5 × 119mm (Minimum measuring Diameter φ 16)
Options	V type probe adaptors※	—	
Accessories	Thickness standards, Zero plates for testing(Fe/NFe)	Thickness standards, Zero plates for testing(Fe)	
Measuring objects	Fe: coating, lining, thermal spray film, plating (except electrolyte nickel plating), etc. on magnetic metal substrate like iron, steel. NFe: relatively general use objects like insulated films on non-magnetic metal substrate like aluminum, copper, etc.	Coating, lining, thermal spray film, plating (except electrolyte nickel plating), etc. on magnetic metal substrate like iron, steel. Small parts, narrow places, and so on.	Inside of a small diameter tubes, narrow places, and so on.

※ 3 kinds of V type probe adaptors (less φ 5、φ 5~10、φ 10~20)

◆ Probe (option)

Model	SFe-2. 5 ^{※1} /SFe-2. 5L	SFe-2. 5LwA	SFe-10	SFe-20
Measuring method	Electromagnetic type			
Measuring range	0~2. 50mm		0~10mm	0~20mm
Resolutions	1 μm: 0~999 μm 0. 01mm: 1. 00~2. 50mm by switching 0. 1 μm: 0~400 μm 0. 5 μm: 400~500 μm		1 μm: 0~999 μm 0. 01mm: 1~10mm	1 μm: 0~999 μm 0. 01mm: 1~5mm 0. 1mm: 5~20mm
Accuracies (to flat, smooth face)	0~100 μm: ±1 μm or ±2% of reading 101 μm~2. 50mm: ±2%		0~3mm: ±(5 μm+3% of reading) 3. 01mm or over: ±3%	
Probes	One point contact constant pressure type V-cut SFe-2. 5: about φ15×47mm SFe-2. 5L: about 18×22×67mm	One point contact constant pressure type Measuring part: about 24×27×56mm Full length (flexible): about 546~1530mm	One point contact constant pressure type V-cut about φ21×47mm	One point contact constant pressure type V-cut about φ35×55mm
Options	V type probe adaptors ^{※2} /—	—	—	—
Accessories	Thickness standards, Zero plates for testing (Fe)	Thickness standards, Zero plates for testing (Fe), Carring case	Thickness standards, Zero plates for testing(Fe)	
Measuring objects	Coating, lining, thermal spray film, plating (except electrolyte nickel plating), etc. on magnetic metal substrate like iron, steel.	For coating thickness on remote, unreachable place of coating, lining on magnetic metal substrate like iron, steel.	On magnetic metal substrate like iron, steel For relatively thicker objects	For thick objects

※1: Heat-resistant (about 200°C) for probe Fe-2.5

※2: 3 kinds of V type probe adaptors (less φ5、φ5~10、φ10~20)

◆ Probe (option)

Model	SNFe-2. 0/SNFe-2. 0L	SNFe-0. 6	SNFe-5	SNFe-8
Measuring method	Eddy current type			
Measuring range	0~2. 00mm	0~600 μ m	0~5. 00mm	0~8. 00mm
Resolutions	1 μ m: 0~999 μ m 0. 01mm: 1. 00~2. 00mm by switching 0. 1 μ m: 0~400 μ m 0. 5 μ m: 400~500 μ m	1 μ m: 0~600 μ m by switching 0. 1 μ m: 0~400 μ m 0. 5 μ m: 400~500 μ m	1 μ m: 0~999 μ m 0. 01mm: 1~5mm	1 μ m: 0~999 μ m 0. 01mm: 1~8mm
Accuracies (to flat, smooth face)	0~100 μ m: $\pm 1 \mu$ m or $\pm 2\%$ of reading 101 μ m~2. 00mm: $\pm 2\%$	0~100 μ m: $\pm 1 \mu$ m or $\pm 2\%$ of reading 101~600 μ m: $\pm 2\%$	0~3mm: $\pm (5 \mu$ m+3% of reading) 3. 01mm or over: $\pm 3\%$	
Probes	One point contact constant pressure type V-cut SNFe-2. 0: about $\phi 15 \times 47$ mm SNFe-2. 0L: about $18 \times 22 \times 67$ mm	One point contact constant pressure type V-cut about $\phi 13 \times 45.5$ mm	One point contact constant pressure type V-cut about $\phi 20.5 \times 47$ mm	One point contact constant pressure type V-cut about $\phi 35 \times 59$ mm
Options	V type probe adaptors [※] /—	—	—	—
Accessories	Thickness standards, Zero plate for testing (NFe)			
Measuring objects	Insulated films on non-magnetic substrate metal like aluminum, copper, etc.			
	Relatively general use objects	For high stability with narrow bars, small tubes, minute pieces	For relatively thicker objects	

※ 3 kinds of V type probe adaptors (less $\phi 5$ 、 $\phi 5 \sim 10$ 、 $\phi 10 \sim 20$)

Reference (measurement principles)

● Electromagnetic type

When metals approach to AC- magnetic fields emitted from probe, the metal and the magnet pull each other.

It makes the pulling force stronger as they come closer.

In other words, it makes the magnetic density higher as they come closer. On the contrary, it weakens the magnetic density as they move away from each other.

This symptom means that magnetism emitted from probe has Higher Transferability when they come closer, and lower Transferability when they move away from each other.

These levels of transferability of the magnetism co-relate with thicknesses of films coated on substrates.

By analyzing correlations of transferability/less transferability (Reluctance), and thicknesses of the films on the substrates,


the correlated values can be converted to the thickness, actually by measuring the Reluctance to be processed.

Because it is difficult to observe and measure magnetic volumes,

it is necessary that the Reluctance volumes be converted

to electric volumes using coils and methods of the Principle of Electromagnetic Induction so that the measured values can

be processed and converted to the thickness values.



● Eddy Current Type

The eddy current is induced on the surface of metals when metals approach to alternating current fields emitted from probe.

As the metal comes closer to the probe, the eddy current increases and the magnetic field density becomes high.

On the contrary, as the metal move away from the probe, the eddy current decreases and the magnetic density becomes low: Correlations of between density of magnetic field and film thicknesses on the substrate are analyzed beforehand.

It measure the thicknesses by converting to the thickness value from the magnetic density measured through the above correlations.

Because it is difficult to observe and measure the density of a magnetic

field, it is necessary that a coil be put in magnetic fields

and converted to electric volumes for measurements

using the Principle of Electromagnetic Induction

so that the measured value can be processed and


converted to the thickness value. Generally in the eddy

current type, it varies in measurement range on non-

magnetic substrate by dividing substrates by a high-wave

transferable like Alumi and Copper and non-transferable

like irons to optimize the measurement methods.



◆ Products sold ◆

Coating thickness meter, Pinhole detector,
Moisture meter, Concrete covermeter, Condensator,
Needle detector, Iron piece detector, Viscosity cup



SANKO ELECTRONIC LABORATORY CO.,LTD.

Head office: 1677 Hisasue, Takatsu-ku, Kawasaki 213-0026, Japan

Tokyo branch: Shibata Bldg., 2-6-4, Uchikanda, Chiyoda-ku, Tokyo 101-0047, Japan

TEL: 81-3-3254-5031 FAX: 81-3-3254-5038

Osaka branch: Wake Bldg., 1-11-9, Higashitenma, Kita-ku, Osaka 530-0044, Japan

TEL: 81-6-6881-1230 FAX: 81-6-6881-1232

Sendai branch: Bonheur Est, 2-5, Teppomachinaka, Miyagino-ku, Sendai 983-0868, Japan

TEL: 81-22-292-7030 FAX: 81-22-292-7033

Nagoya branch: Meihoku Bldg., 3-11-27, Kinjo, Kita-ku, Nagoya 462-0847, Japan

TEL: 81-52-915-2650 FAX: 81-52-915-7238

Fukuoka branch: 11-11, Naraya-cho, Hakata-ku, Fukuoka 812-0023, Japan

TEL: 81-92-282-6801 FAX: 81-92-282-6803

URL <https://www.sanko-denshi.co.jp> E-mail info@sanko-denshi.co.jp